

## How to collect raw data for thermal camera

### Purpose

When thermal's image displays exception, it needs you to collect some information for further check.

### Preparation

1. Download the RawDataCaptureTool.

**Note:**

Tool can be found on FTP. The path: /17 Thermal/Product support/04 Tool/

### Steps:

1. Select RawCapture.exe and run it.







Figure 1


2. As the Figure2 shown, connecting the device and login it.







3. Click Setting→Raw Data Path to choose the saving path.





4. Uncheck ①&② and make sure the value of ③ is 0.  
Click ④ Video Record button to start, finally click this button again to stop.





5. Go to the saving path, send the following file to us.

Name	Date modified	Type
 Record_20180930170134	2018/9/30 17:01	File

**First Choice for Security Professionals**

**HIKVISION Technical Support**