HIKVISION

How to upgrade firmware to handheld thermography camera

Purpose

Upgrading new firmware to handheld thermography camera.

Preparation

1. *Make sure that computer has installed SADP tool.*
2. *Download the firmware file to the desktop.*

Steps

1. *Make the computer and device in the same network.*
   1.1 *Select the **Local Settings** (⚙) from the main menu.*
   1.2 *Go to **Local Settings>Device Settings>Wi-Fi Settings**.*

Figure 1

   *1.3.1 Tap on **WLAN Hot Spot** to enable the WLAN hot spot function. Tap **Set WLAN hot spot** to display password. The default password is 12345678.*
   *1.3.2 Or Tap on **Connect to Wi-Fi** to enable Wi-Fi, and the searched Wi-Fi will be listed below.*
   1.4 Connect your computer to the WLAN Hot Spot of the camera or the same Wi-Fi source of the camera. (Take WLAN Hot Spot for example)


Figure 2

2. *Search the device by SADP tool. Then active the device and set the strong password to the device.*

Figure 3

3. Make sure the IP address of device and computer is in the same network segment. Then connect the device via web browser.

Figure 4

4. Select **Configuration>System>Maintenance**, find the firmware file, then click Upgrade to update new firmware file to the device.

Figure 5

First Choice for Security Professionals

***HIKVISION* Technical Support**