

**В ПРОШИВКАХ 5.4.0 SSH НЕ РАБОТАЕТ  
С ПРОШИВОК 5.3.X и 5.4.X ДО БОЛЕЕ  
РАННИХ ОТКАТИТЬСЯ НЕЛЬЗЯ**

**R1**

DS-2CD4012F-(A)(P)	DS-2CD4132FWD-I(Z)	DS-2CD4312F-PTZ
DS-2CD4012FWD-(A)(P)	DS-2CD4212F-I(Z)(S)(H)	DS-2CD4324F-I(Z)(S)(H)
DS-2CD4024F-(A)(P)	DS-2CD4212FWD-I(Z)(S)(H)	DS-2CD4324F-PTZ
DS-2CD4032FWD-(A)(P)	DS-2CD4224F-I(Z)(S)(H)	DS-2CD4332FWD-I(Z)(S)(H)
DS-2CD4112F-I(Z)	DS-2CD4232FWD-I(Z)(S)(H)	DS-2CD4332FWD-PTZ
DS-2CD4112FWD-I(Z)	DS-2CD4312F-I(Z)(S)(H)	DS-2CD6412FWD
DS-2CD4124F-I(Z)	DS-2CD4312FWD-I(Z)(S)(H)	

**R3**

DS-2CD4024FWD-(A)(P)	DS-2CD4A26FWD-IZ(H)(S)	iDS-2CD6124FWD-I(Z)/F
DS-2CD4124FWD-(I)(Z)	DS-2CD6026FHWD-(A)	DS-2CD4612FWD-IZ(H)(S)
DS-2CD4224FWD-I(Z)(S)	DS-2CD6213F	DS-2CD4026FWD-(A)(P)
DS-2CD4324FWD-I(Z)(H)(S)	DS-2CD6223F(H)	DS-2CD4126FWD-IZ
DS-2CD4524FWD-I(Z)(H)	DS-2CD6233F	DS-2CD4526FWD-IZ(H)
DS-2CD4524FWD-I(Z)(M)	iDS-2CD6233F/F	DS-2CD4626FWD-IZ(H)
DS-2CD4624FWD-IZ(H)(S)	DS-2CD6026FHWD-(A)	DS-2CD4A26FWD-IZ(H)(S)
DS-2CD4A24FWD-IZ(H)(S)	iDS-2CD6024FWD-(A)/F	DS-2CD6026FHWD-(A)(P)
DS-2CD4026FWD-(A)	iDS-2CD6024FWD-(A)/B	iDS-2CD6024FWD/(B/F)
DS-2CD4126FWD-(I)(Z)	iDS-2CD6124FWD-I(Z)/C	DS-2CD6226FWD-IZ(H)(S)
DS-2CD4526FWD-I(Z)(H)	iDS-2CD6124FWD-I(Z)/H	iDS-2CD6412FWD/C
	iDS-2CD6124FWD-	

**R4**

DS-2CD4025FWD-(A)(P)	DS-2CD4185F-IZ	DS-2CD4635FWD-IZ(H)(S)
DS-2CD4035F-(A)(P)	DS-2CD41C5F-IZ	DS-2CD4665F-IZ(H)(S)
DS-2CD4035FWD-(A)(P)	DS-2CD4525FWD-IZ(H)	DS-2CD4685F-IZ(H)(S)
DS-2CD4065F-(A)(P)	DS-2CD4535F-IZ(H)	DS-2CD46C5F-IZ(H)(S)
DS-2CD4085F-(A)(P)	DS-2CD4535FWD-IZ(H)	DS-2CD4A25FWD-IZ(S)
DS-2CD40C5F-(A)(P)	DS-2CD4565F-IZ(H)	DS-2CD4A35F-IZ(S)
DS-2CD4125FWD-IZ	DS-2CD4585F-IZ(H)	DS-2CD4A35FWD-IZ(S)
DS-2CD4135F-IZ	DS-2CD45C5F-IZ(H)	DS-2CD4A65F-IZ(S)
DS-2CD4135FWD-IZ	DS-2CD4625FWD-IZ(H)(S)	DS-2CD4A85F-IZ(S)
DS-2CD4165F-IZ	DS-2CD4635F-IZ(H)(S)	DS-2CD4AC5F-IZ(S)