HIKVISION

How to Use Temperature Screening Version iVMS-4200

1. Download and installation

Dowload linkage：*ftp://hikftp.hikvision.com:400/00 Oversea Products/09 Software & Tools/01 iVMS-4200/1 Software Version List/Fever/*

Please tick to choose the Data Retrieval and Report Module when install.

2. Temperature screening DeepinMind NVR + 4200

1) Add the DeepinMind NVR to iVMS-4200

Note:

Before add the NVR，please upgrade the NVR to temperature screening version and finished all configuration. For NVR configuration please refer to the *AI Fever screening configuration guide* which can be download in FTP. ftp://hikftp.hikvision.com:400/01 All Materials of Temperature Screening Solution/02 NVR/04 Technical Material/

2) Show in AI Dashboard

Step1: Go to AI Dashboard > Skin-Surface Temperature


Step2: Choose live view channel .

Step3: Configure alarm type configure alarm type. For DeepinMind NVR，we suggest choose face picture comparison alarm.

Step4: Configure alarm pop-up window


Step5: Configure alarm audio

3) Face Picture Retrieval & Export

4) Report

Note:

Only DeepinMind NVR support Face feature retrieval & Skin-surface Temperature now.

3. Thermal camera + iVMS-4200

1) Add Thermal Camera

2) Display in AI Dashboard

3) Alarm picture storage configuration and search.

Step1：Go to System cofiguration > Event Picture Storage

Step2：Go to System cofiguration > Event Picture Storage

Note:

The alarm picture is storage at storage location you set. For example, *D:\iVMS-4200alarmPicture.* But pay attention, the file in this path is a summary of alarm picture and can not open. Only can be searched in iVMS-4200 event center and export.

Step3：Search alarm and export

First Choice for Security Professionals
HIKVISION **Technical Support**